





i i		Control Joint Dimentions			
ARTICLE	HEIGHT H (mm)	THICKNESS T (mm)	SIGHTLINE A (mm)	LENGHT/PC (mm)	ORDER CODE
KCME	8,10,12 14,16,20	01	06	2.5	KCME-H
KCMEX	25,35,45	01	06	2.5	KCMEX-H

KCME.....

» When ordering specify the color of slightline.

Dark grey for rigid and flexible part Colors Light grey for rigid and flexible part

Laying instructions

- Select KCME width according to the desired.
- 2 Trowel tile adhesive over the area.
- 3 Press the KCME profile into place and align on top of the already laid tile.
- Solidly embed the tiles so that the tiled surface is flush with the top of the profile, the profile should not be higher than the tiled surface.
- **5** Fill the joint completely with grout.

Maintanance

To achieve the most favorable performance, please follow the maintenance instructions below.

- » Regular maintenance of the Profile will help prolong the life of the product. A build up of dirt and grease can prove hazardous and also affect the appearance of the profile.
- » Firstly, any excess dirt should be removed by using a quality vacuum cleaner or a soft bristle brush. A harsh bristle will mark the material.
- » The profile should then be cleaned by using a soapless, neutral detergent in warm water on a damp cloth. They should then be rinsed with clean water, again using a soft, damp cloth.
- » Polishes will reduce anti-slip properties and solvent cleaners are not suitable.